

Features

- Call and Reset button
- IP65 water resistant
- In addition to the Call button, buttons are provided for Staff Emergency, Check-In, and Rounding
- Includes screws, anchors, and a wall-mount bracket
- Long-lasting and replaceable battery
- Low battery indication
- Optional pull cord (SF574) installed

Description

The SF573 is a wireless, surface-mountable station that includes a Call button, a pull cord, an LED for call indication, and a Reset button. The SF573 also has three additional call buttons for Staff Emergency, Check-In, and Rounding.

When a call is placed, it annunciates on any master stations, duty stations, staff apps, and monitors installed on the Tek-CARE system zoned to display the call. The SF573 stations are configured using the LS450 Config Tool software. By default, the push button and handset place an “Emergency” call.

The SF573 may be directly surface-mounted to a non-metallic surface, or mounted using a non-metallic single-gang backbox or low voltage ring.

Required Components

NC570 Receiver
NC571 Repeater

Optional Components

SF574 Call Cord



SF573 Single Bed Multifunction Station

Specifications

Dimensions:	4.2"H × 3.4"W × 0.86"D (106 mm × 87 mm × 22 mm)
Connections:	RJ12 4P4C jack for SF574
Battery:	BA007 ×2 (CA2477)
Mounting:	Surface-mounted; attach back plate to a standard plastic single-gang ring or single-gang box. Do not use the metal rings or boxes as it interferes with the wireless signal.
Construction:	PC board with quality electronic components.

TekTone® has designed Tek-CARE®570 to work as a system. Its Tek-CARE®Appliance Server has been carefully designed and matched to work with Tek-CARE570 wireless and wired peripherals. TekTone will not warrant or support components of Tek-CARE570 that are purchased separately unless the components are add-ons to previously sold systems. TekTone will also not warrant or support a system that is a mix of TekTone and non-TekTone parts, unless prior permission has been obtained. A site survey must be performed and submitted before ordering a Tek-CARE570 system. In order to track our systems and to inform facilities of software upgrades, full site information (site name, address and phone number) will be required when ordering. Site information and Tek-CARE Appliance Server warranty numbers will also be required when requesting technical support.