SF118/2C, SF118/4C Emergency Call Station IL576 Specification Sheet

Tek-ENTRY Apartment Entry Systems • Rev. 12 - 4/2022

Features

- Call-placed indicator
- Call cancellation only at point of origin
- Flame retardant (UL® 94V-0) plastic faceplate
- Contacts to signal dome light, and buzzer or bell

Description

The SF118C Emergency Switch is available in two models. Both models feature a rugged, long-life, positive-acting switch mounted on a flame retardant (UL® 94V-0) plastic faceplate marked **EMERGENCY** that includes a red LED. Signaling an emergency requires just a short pull in any direction on the 6' long nylon cord. The signal cannot be canceled except at the point of origin. The SF118/2C provides two contacts, one to signal a dome light and master station, and one to signal a buzzer or DC bell. The SF118/4C provides two additional contacts that may be used to operate additional signaling devices as needed.

Specifications

Dimensions: 4.5"H × 2.75"W × 1.5"D

 $(114 \text{ mm} \times 70 \text{ mm} \times 38 \text{ mm})$

Switch: SF118/2C: PDT

SF118/4C: PDT

Construction: Switch and lamp are ,ounted to a flame

retardant (UL® 94V-0) plastic faceplate

Call-Placed Red LED

Light:

Connections: Wire leads

Mounting: Standard single-gang electrical box



SF118/2C, SF118/4C Emergency Call Station

Required Components

CM800 Emergency Call System