

Tek-CARE NC150 and NC200 Nurse Call Systems • Rev. 8 - 5/2022

Features

- May be used as a retrofit for the IR151N or IR152N station with IH106N backbox; requires two CL207 mounting adapters
- Push-button calling
- Call-placed indicator
- In-use indicator when intercom audio path is active
- Reset button
- Sensitive speaker/microphone
- Durable flame retardant (UL® 94V-0) plastic panel

Description

The IR151B or IR152B Patient Station provides for efficient use of the nursing staff by permitting fast and reliable communication between staff and patient. Calling the nurse is accomplished by pressing the call button on the end of a 6' or 10' long call cord. A non-resettable call is registered if the call cord is accidentally removed from its jack.

Call-placed assurance and intercom operation are indicated by solid-state LEDs. The speaker/microphone is sensitive enough to assure clear conversation, even with weak patients. A reset button is provided on the durable, flame retardant (UL® 94V-0) plastic panel.

Listings



UL 1069 Listed; UL $^{\mathbb{R}}$ File Number E71599.

Specifications

Dimensions: 4.5"H × 6.375"W × 2.375 "D

 $(114 \text{ mm} \times 162 \text{ mm} \times 60 \text{ mm})$

Construction: Flame retardant (UL® 94V-0) plastic

Speaker: $2.5" \times 2.5"$ Connections: Plug-in type

Housing: Steel City #H3BD with Steel City #3GC

plaster ring, or TekTone #IH353 box with IH352 ring, or equal, or if a smaller box is needed, use ARC-CO #2GB with ARC-CO

#3GC ring. Horizontal mount



IR151B Single Patient Station

IR152B Dual Patient Station



Required Components

Tek-CARE NC150 or NC200 Nurse Call System