

Features

- Universal IR television remote-built-in
- UL® 1069 Listed
- Oxygen Safe
- Flame-retardant (UL® 94V-0) high-impact plastic
- Long lasting switches
- 8' cord with DIN plug and security clip
- Provides pillow speaker intercom and light controls when used with the appropriate station modules

Description

The SF401KIRL Pillow Speaker may be used with Tek-CARE400 IR411-series and IR412-series patient stations, Tek-CARE400 P5 IR411P5 and IR412P5 patient stations, and Tek-CARE300III IR319-series and IR320-series patient stations. The SF401KIRL features an eight-foot cord and an eight-pin DIN connector.

The SF401KIRL pillow speaker provides call placement to the master station, as well as a built-in universal infrared remote control. This IR remote control may be programmed to control numerous brands of consumer-grade televisions, such as LG, Samsung, Magnavox, Toshiba, and many more. Programming instructions and codes are included with each SF401KIRL pillow speaker. The IR remote control is powered by user-replaceable AAA batteries.

When used in conjunction with the appropriate TekTone® pillow speaker modules, the pillow speakers also supply two-way, hands-free communication with the master station.

Push buttons are provided to call the nurse, plus TV power, channel selection up/down, Closed Captioning, mute, and two light controls. Buttons are also provided for volume up/down, last channel, sleep timer, and for direct channel access.

Note that the SF401KIRL does not transmit audio from the television through the pillow speaker. If this function is required, hospital-grade televisions must be installed, and TekTone SF41ZKL pillow speakers must be used.

Listings



UL® 1069 listed



SF401KIRL Pillow Speaker

Specifications

Dimensions:	9"H × 3.125"W × 1.375"D Cord: 8' long
Construction:	Flame-retardant (UL® 94V-0) plastic

Required Components

for Tek-CARE® 300III Nurse Call Systems:

IR319- or IR320-series Patient Station
PM311C or PM312C Pillow Speaker Intercom Module
PM321B or PM322B Light Control Module
or

for Tek-CARE® 400 Nurse Call Systems:

IR411- or IR412-series Patient Station
PM421 or PM422 Pillow Speaker & Bed Interface Module
or

for Tek-CARE® 400 P5 Nurse Call Systems:

IR411P5 or IR412P5 Patient Station
PM421P5/PM422P5 Pillow Speaker Module